

DROP MECHANISM LUBRICATION

Periodic lubrication of the drop mechanisms will insure smooth, crisp drops. We recommend that you use 3-IN-ONE oil after about 500 adjustments or once/month, whichever comes first. If the drops have not been lubricated on a regular basis, it is useful to first "clean" the plungers using WD-40. See instructions below.

HEADPIECE DROP




Routine lubrication:

1. Raise the back of the headpiece.
2. Apply 3-IN-ONE into the hole of the white drop mechanism housing as shown in the photo. Allow a few minutes for the lubricant to penetrate the mechanism before using the headpiece drop.

If the drop has not been lubricated on a regular basis:

1. First "clean" the plunger from accumulated dust and debris by applying WD-40 (as shown above) and then drop the headpiece several times.
2. Apply 3-IN-ONE oil to lubricate the drop (as described above).

PLUG LOCATIONS



For your reference, the electric and foot pedal plugs are located at the base of the motor shaft, under the wood plate.

PELVIC DROP



Routine lubrication:

1. Cock each drop section and raise the thoracic section to its inclined position. This will expose the lubrication hole in the drop mechanism housing on the opposite side of the cocking handle.
2. Apply 3-IN-ONE oil into this hole. Allow a few minutes for the lubricant to penetrate the mechanism before using the drop.

If the drop has not been lubricated on a regular basis:

1. First "clean" the plunger from accumulated dust and debris by applying WD-40 (as shown above) and then drop the section several times.
2. Apply 3-IN-ONE oil to lubricate the drop (as described above).

UPHOLSTERY

Normal day to day soil on the vinyl upholstery can be removed with neutral soap and warm water, and then rinsed thoroughly. Avoid harsh detergents and powdered abrasives. Areas coming in contact with hair, body oils or perspiration should be washed frequently. Remove stains immediately to prevent the possibility of them becoming permanent. In the event of damage, pre-sewn replacement upholstery is available from Thuli Tables.